


OWNER'S MANUAL



TRINITY 3-Bag Laundry Station w/Wheels Model # TBFPBR-2101C

Important / Important / Importante

FOR 3D ASSEMBLY INSTRUCTIONS

POUR DES DIRECTIVES D'ASSEMBLAGE 3D

PARA INSTRUCCIONES DE ENSAMBLAJE EN 3D












PARTS LIST

Your TRINITY 3-Bag Laundry Station w/Wheels should include the following parts. Please inspect box contents to ensure you have received all components.

If you are missing any parts, need assistance with assembly or have questions, please contact TRINITY Customer Service: 800.985.5506 or customerservice@trinityii.com. Parts can also be requested online via our "Contact Us" section at www.trinityii.com.

All tools required for assembly are included.




ASSEMBLY INSTRUCTIONS

STEP 1


Lay the BAMBOO FRAME (A) on its side with the TRINITY logo facing out. Attach the BOTTOM SHELF (B) to the BAMBOO FRAME (A) using SHORT SCREWS (J) and the HEX KEY (L).


Then attach POLES (D) to the BAMBOO FRAME (A), using SHORT SCREWS (J) and the HEX KEY (L).



STEP 2

Starting at the top, push LONG SCREWS (I) through the none threaded holes of SIDE SHELF (C) and second BAMBOO FRAME (A) with the TRINITY logo facing out. Tighten each LONG SCREW (I) to POLE (D) and BOTTOM SHELF (B) with HEX KEY (L).







ASSEMBLY INSTRUCTIONS

STEP 3


Using SHORT SCREWS (J) attach the third BAMBOO FRAME (A) with the TRINITY logo facing out.






STEP 4

Screw CASTERS (G+H) into the nuts at the bottom of the BAMBOO FRAMES (A). Turn clockwise to screw in place. Make sure the LOCKING CASTERS (G) are on the same side.



<u>Use the provided CASTER WRENCH (K) to tighten the CASTERS (G+H)</u> completely. Failure to do as instructed could result in the caster stem <u>breaking</u>.





ASSEMBLY INSTRUCTIONS

STEP 5

Stand the unit upright. Insert the LAUNDRY BAG HANDLE (E) through the loops at the top of the LAUNDRY BAG (F). Repeat for remaining (5) LAUNDRY BAG HANDLES (E).

Hang the LAUNDRY BAGS (E+F) on the POLES (D) as shown in the diagram.






SERVICE PARTS LIST — TBFPBR-2101C

TRINITY Customer Service provides the following replacement parts:

	Part Number	Description		Part Number	Description
1)	PBR-05-013-1675	Handle	7)	ZSV-99-010-2008	Locking Caster
2)	XWH-24-002-0814	Laundry Bag	8)	XXX-97-002-0001	Wrench
3)	ZBK-01-002-0625	Long Screw	9)	PBR-03-017-2617	Bottom Shelf
4)	PBR-03-017-1417	Side Shelf	10)	ZBK-01-002-0618	Short Screw
5)	LNA-14-007-1730	Bamboo Frame	11)	XXX-97-001-0001	Hex Key
6)	ZSV-99-009-2008	Non-locking Caster	12)	PBR-13-007-2600	Pole



WARNINGS

- **1. Read and understand all instructions.** Failure to follow all instructions may result in injury and/or damage.
- **2. Use the provided caster wrench to tighten casters completely.** Failure to do as instructed could result in the caster stem breaking thereby causing the shelving rack to collapse.
- 3. The warnings, cautions, and instructions discussed in this manual cannot cover all possible conditions or situations that may occur. The user must always be aware of their environment and ensure that they use the product in a safe and responsible manner.
- **4. Do NOT modify the product in any way.** Unauthorized modification may impair the function and/or safety of the product, and may affect the life of the product.
- **5. Check for damaged parts.** Before using this product, carefully check that all parts are in good condition, and that the product will operate properly and perform its intended function. Check for damaged parts and any other conditions that may affect the operation of this product. Replace damaged or worn parts, and never use this product with a damaged part.
- 6. Do NOT overload the product.

Weight capacity per bag	15 lb
Total weight capacity of sorter	66 lb

7. Do NOT stand on the bottom shelf.

CARE AND MAINTENANCE

- Avoid harsh, abrasive cleaners, and other corrosive chemicals.
- Laundry bags are made of 100% polyester, wipe them clean by wet towel or sponge with mild detergent where needed.
- Do NOT wash laundry bags in hot water. Hand wash only in cold water after removing bag handles, line dry in shade only. Do NOT wring or rub laundry bags. Do NOT bleach, iron, dry clean or tumble dry laundry bags.
- Bamboo can be maintained with mineral oil for best results.
- The product is designed for indoor use.

PRODUCT REGISTRATION

Thank you for purchasing a TRINITY 3-Bag Laundry Station w/Wheels. In order to register your product and receive streamlined customer service, please fill out the following Product Registration Form and (1) fax the form to 310.347.4134 (2) complete the Product Registration Form online at www.trinityii.com or (3) scan and email the form to customerservice@trinityii.com. Include a copy of your original receipt with your submission.

First Name:	Last Name:					
Address:						
City:	State: Zip Code:					
Email Address:	Phone:					
Product Model #: TBFPBR-2101C	Purchase Date: / /					
Location of Purchase:						
Please rate the importance of each feature (1=least important; 10=most important) Quality Price Size/Capacity Appearance Other						
How did you hear about our product? Magazine Ad Catalog Salesperson Word of Mouth Internet Store Display Other						
Marital Status: Household Income: Education: Primary Residence: Comments/Suggestions: Single Below \$56 High School Own	☐ Married 0,000 ☐ \$50,000-\$150,000 ☐ \$150,000+ ool ☐ College ☐ Graduate School ☐ Rent					

1 YEAR LIMITED WARRANTY

TRINITY 3-Bag Laundry Station w/Wheels Model # TBFPBR-2101C

Trinity International Industries ("Trinity") warrants to the original consumer purchaser ("Purchaser") of the TRINITY 3-Bag Laundry Station w/Wheels ("Product") that each Product shall be free from defects in workmanship and materials for a period of 1 year from the date of original purchase. Trinity's obligation under this warranty shall be limited to repair or replacement of, or adequate compensation for the Product which shall not be greater than the amount of the purchase price of the Product, at the option of Trinity, during the warranty period. All replaced parts and Products become the property of Trinity and must be returned to Trinity.

This warranty excludes normal wear and tear of the Product and its parts or components, and damage arising from any of the following: negligent use or misuse of the Product, use contrary to this User's Manual, or alteration by any one other than Trinity. The warranty period of 1 year shall not be extended or renewed by the repair or replacement of, or compensation for, the Product. Any warranty implied by applicable law is limited in duration to one year from the date of purchase and is subject to the same conditions and limitations as is provided for our express warranty.

Except as set forth herein, and to the extent of applicable there are no warranties on this Product either express or implied, and Trinity disclaims all warranties including, but not limited to, any implied warranties of merchantability, infringement or fitness for a particular purpose. No warranty or guarantee given by any person, firm, or corporation with respect to this product shall be binding on Trinity.

If your Product is defective or otherwise requires service or parts, please call TRINITY Customer Service toll-free at (800) 985-5506, between 5:00 a.m. and 5:00 p.m., PST. Please tell us which model you purchased, the date of the purchase, and the problem with your Product. A copy of your original purchase receipt must accompany your service request.

LIMITATION OF REMEDIES AND LIABILITY

Trinity (and its employees, officers, members, managers, affiliates and assigns) shall not be liable for any incidental, consequential, special, indirect, remote, special or punitive damages for breach of any warranty, express or implied, including, but not limited to, lost profits, lost savings, loss of anticipated benefits and attorneys' fees, which arise out of the purchase, use or inability to use the Product, whether arising out of contract, negligence, strict tort, product liability, or any other legal theory on which a claim is based. As noted above, to the extent damages are allowed by our express warranty or by applicable law, those damages may not exceed the purchase price paid for the Product. Without limiting the foregoing Purchaser assumes all risk and liability for loss, damage or injury to Purchaser and Purchaser's property and to others and their property arising out of the use, misuse, or inability to use this Product. This limited warranty shall not extend to anyone other than the original purchaser of this product, is nontransferable and states your exclusive remedy.

Some states do not allow the exclusion or limitation of incidental, consequential, special, or punitive damages, so the above limitation or exclusion may not apply to you. The above warranty gives you specific legal rights, and you may have other rights which vary from state to state.

QUESTIONS? NEED PARTS? WE ARE HERE TO HELP!

Please feel free to contact us. There are no questions too small, or any problems too big. We're committed to providing our customers with the highest level of service.

TRINITY Customer Service

TEL: 800.985.5506

FAX: 310.347.4134

EMAIL: customerservice@trinityii.com

Monday through Friday 5:00 AM - 5:00 PM (PST)

www.trinityii.com